NOBODY™ AUDIO

USER MANUAL

VP ZERO

SCAN TO DOWNLOAD THE NOBODY AUDIO APP

NBA-VP ZERO-001 EN/ VERSION1.0

1 Package Contents

- NOBODY VP0 True Wireless Earbuds (L & R)
- Charging Case
- Silicone Ear Tips — S / M / L
- User Manual & Warranty Information

2 Product Information

Product Name	Wireless Earbuds
Product Model	NOBODY VP0
Max. Output power	≤5.20 dBm (EIRP)
Frequency Range	2402 - 2480 MHz

3 How to Wear

3.1 Choosing Your Ear Tip Size

Start with the pre-fitted medium tips.
If they feel loose or tight, switch to the small (S) or large (L) tips supplied.

3.2 Wearing the Earbuds

Identify the Left (L) and Right (R) earbuds. Insert in the correct orientation, then rotate gently for a secure, comfortable seal.

4 Power On / Off

- Open the charging case — the earbuds power on automatically.
- To power off, return the earbuds to the case and close the lid.

5 Pairing

5.1 First-Time Pairing

- Open the case lid; the LED flashes as the earbuds enter pairing mode.
- Long-press the case button for 3 seconds.
- On your device, open Bluetooth and tap "Add Device".
- Select "NOBODY VP0" from the list to connect.

Once paired, your VP0 reconnects to the last-used device automatically each time it leaves the case.

5.2 Pairing Mode (Manual)

With the earbuds in the case and lid open, long-press the case button for 3 seconds.

5.3 Factory Reset

With the earbuds in the case and lid open, long-press the case button for 10 seconds.

6 Touch Controls

Tap the touch area on either earbud to trigger a function. Functions marked * are defaults and can be reconfigured in the NOBODY Audio app.

Gesture	Earbud	Function
Single Tap	L/R	**Play / Pause***
Double Tap	L/R	**Next Track***
Triple Tap	L/R	**Previous Track***
Long Press 3s	R	**Volume Up***
Long Press 3s	L	**Volume Down***
Single/ Double Tap	L/R	**Answer / End Call**
Long Press(in call)	L/R	**Reject Call**
Case button 10s	Case	**Factory Reset**



7 Wear Detection

- Removing both earbuds pauses playback; reinserting either one resumes it.
- Playback only resumes if an earbud is replaced within 30 seconds.

8 Dual-Device Connection

Connect to two devices at the same time and switch audio between a phone, computer or tablet.

9 LED Indicator Status

Pairing Successful	Blue light, 2 seconds
Earbuds Battery < 20%	Red flashes, 1 second
Charging Case Battery < 20%	Red flashes, 1 second
Charging Case Battery ≥ 20%	Green light, 1 second
Pairing Mode Active	LED flashing
First-Time Connection (lid open)	Flashes — press case button

10 Battery Level Display

When the earbuds are in the charging case, it shows their battery level first; a low-battery alert appears when power runs low.

11 Download the NOBODY Audio App

Download the NOBODY Audio app for added features and firmware updates. In the app, Tap "Add Device", then select "NOBODY VP0" to connect. Available on the App Store (iOS) and Google Play (Android).

NOBODY Audio

12 Charging

- Charge the case with the supplied USB-C cable via the charging port. With the lid closed, the case charges the earbuds inside it.
- Use a charger rated 0.3 W – 0.5 W for safe, efficient charging.
- Do not charge for more than 12 hours.

0.3 — 0.5 W

13 Safety & Security

Please read all information before use to ensure safe and proper operation.

- Operate the device between 0 °C and +35 °C; store the device and accessories between −10 °C and +50 °C. Extreme temperatures may cause malfunction, and battery performance may drop below 5 °C.
- Charge in a well-ventilated area between 5 °C and 35 °C. Fast charging may not engage below 15 °C or above 35 °C.
- Do not charge the battery for more than 12 hours.
- The adapter is the means of disconnecting the device from the mains supply — keep it close to the equipment and easily accessible.
- Use only manufacturer-approved chargers, cables, batteries and accessories, to prevent electric shock, fire or explosion.
- Do not replace, disassemble, modify or physically damage the battery. This can cause leakage, overheating, explosion or fire.
- Keep the device and battery out of direct sunlight and away from heat sources and low-pressure environments. Prolonged exposure may cause leakage or, in extreme cases, explosion.
- The battery sustains hundreds of charge cycles; its capacity gradually decreases over time. This is normal and not a defect.
- Dispose of the battery separately from household waste, in line with local regulations. Improper handling or damage can cause fire or explosion.

13 Safety & Security

- Do not use the device where dust, smoke, moisture, dirt or strong magnetic fields are present; these can permanently damage internal components.
- If any part of the product is cracked or damaged, stop using it and contact an authorised service centre or the retailer where it was purchased.
- To protect your hearing, avoid high volume for long periods. Sustained high sound pressure can cause temporary or permanent hearing damage.
- Excessive volume can cause hearing loss, buzzing, tinnitus or hyperacusis. Avoid full volume and limit listening to about one hour per day at medium volume.
- Switch off the device in any potentially explosive atmosphere, including near blasting sites. Observe all posted safety signs and instructions.
- Follow all safety instructions for specific locations, especially hospitals, health-care facilities, service stations, schools, garages and aircraft.
- Do not use the device while driving. Follow all regulations on mobile-device use in vehicles.
- If you have an electronic implant (pacemaker, insulin pump, neurostimulator, etc.), keep the device at least 15 cm from the implant, or on the opposite side of your body.
- Keep the device and all accessories out of reach of small children. Unsupervised access may cause injury or accidental damage.
- This product contains small parts and sharp edges that may detach and pose a choking or injury hazard. Use by children or minors must be supervised by a parent or guardian.

14 Disposal (WEEE)

This symbol means the product and its battery must be disposed of separately from household waste. Take them to an approved recycling organisation. If unsure, contact your local authority, retailer or waste-disposal service.

14.1 Reduction of Hazardous Substances

Complies with local rules restricting hazardous substances in electrical and electronic equipment.
REACH conformity: nobodyaudio.com/support

PAP

15 EU Regulatory Conformance

15.1 EU Declaration of Conformity

NOBODY TECH Ltd. declares that this Wireless Earbuds (NOBODY VP1) complies with Directives 2014/53/EU and 2011/65/EU.
Full text: www.nobodyaudio.com

16 Regional Consumer Rights

16.1 Australia

Under the Australian Consumer Law, goods carry consumer guarantees that cannot be excluded. For a major failure you may choose a replacement or refund, plus compensation for any reasonably foreseeable loss. Where the failure is not major, goods are repaired or replaced within a reasonable time.

16.2 New Zealand

Under the Consumer Guarantees Act 1993 (NZ), goods carry guarantees that cannot be excluded. For a failure of substantial character you are entitled to a replacement or refund; otherwise the product is repaired or replaced. These guarantees do not apply to goods supplied for business purposes.

AUSTRALIAN CONSUMER LAW

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and to compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if they fail to be of acceptable quality and the failure does not amount to a major failure.

17 Limited Warranty

Thank you for choosing NOBODY. If a defect arises that is not the result of user fault, we provide warranty service in line with local laws and regulations. Keep your proof of purchase — it is required to claim free service within the warranty period.

17.1 Warranty Exclusions

The warranty does not apply where:

- The warranty period has expired.
- The product was accidentally dropped or exposed to water during use.
- Damage results from unauthorised disassembly, modification or other user action.
- Damage results from force majeure (e.g. fire, earthquake, lightning).
- Damage results from use that does not follow the user guide or manual.
- Damage results from use in environments outside the product specifications.
- The warranty card or proof of purchase does not match the product serial number, or has been altered.
- The product serial number (SN) is missing, damaged or illegible.

For full warranty terms, contact NOBODY Support on WhatsApp or visit nobodyaudio.com/support.

18 Company Information

Manufacturer	NOBODY TECH LIMITED
Business Reg. No	80180115
Contact / Website	www.nobodyaudio.com

Unit 1603, 16/F, The L Plaza, 367-375 Queen's Road Central, Sheung Wan, Hong Kong

WARRANTY CLAIMS

To make a claim, keep your proof of purchase and dated receipt, then choose one of the following:

1 Email us

Send your proof of purchase to support@nobodyaudio.com to request a Return Authorisation (RA) number, then return the product as instructed.

2 Return to the retailer

Take the product back to the retailer you bought it from, with your proof of purchase.

All claims must be made within 12 months of the date of purchase.

Listen to NOBODY.

AUDIO

Version 1.0 · www.nobodyaudio.com

52070878